

CAPSURE Sync

The CAPSURE Sync utility is used to keep your CAPSURE instrument up to date with the latest features and color collections by synchronizing. The CAPSURE Sync operation is a two-way synchronization between your instrument and the X-Rite server. To synchronize your CAPSURE instrument, CAPSURE Sync must be running.

The application runs automatically at startup. If the application is manually shut down, start it as follows.

Windows: Clicking Start /Programs/ X-Rite /CAPSURE Sync /CAPSURE Sync.

Mac: Start the application from the Applications/CAPSURE Sync.

To use the application:

1. Plug your CAPSURE instrument into your computer USB port.
2. *Windows* – Double-click the CAPSURE icon in the System Tray to display the main CAPSURE Sync Options dialog. Note: You can also right-click the CAPSURE icon to access options. See the information that follows for a description of these options.
Mac - Open the CAPSURE Sync menu item at the top right of the screen and select Open CAPSURE Sync Options from the menu.

CAPSURE Sync Options dialog

The Sync Options dialog is the main dialog of the application where information on the instrument is display. Changes to the sync setting and manual synchronization can also occur from this dialog.

Storage

Amount of free space left in the instrument

Serial Number

Serial number of the instrument

Firmware Version

Current firmware version of the instrument

Sync Now

Synchronize the instrument with the available fan decks.

Sync selected fan decks only

Only synchronize with the fan decks that are selected in the list.

Fan deck list

Display fan decks available for your instrument.

Status of Last Sync

Time of last successful synchronization. The dialog displays status messages, for example when no instrument is connected or during synchronization.

Show a list of updates before every sync

Displays a list of updates that will be downloaded to the device. Selecting **Yes** downloads the updates to the device. Selecting **No** ends the sync without downloading the updates.

Automatically sync when device is plugged in

Run the sync and checks for updates every time the instrument is plugged into the computer.

OK

Save any option changes and closes the Sync Options dialog.

Cancel

Close the Sync Options dialog without saving changes.

System Tray CAPSURE Sync icon (Windows)

Right-click the CAPSURE icon to access the following options.

CAPSURE Sync Menu (Mac)

Click the menu to access the following options.

Last sync date (or No Device Connected)

Provide the last date the synchronization occurred between the instrument and computer. No device is display if not connected.

Sync Now

Synchronize the instrument with the current sync settings that are available without opening the application window.

Options

Open the CAPSURE Sync Options dialog.

Maintenance

Used to access the maintenance functions for the instrument and application.

Clear device

Deletes all current fan decks and stored records in the instrument.

Back up file cache

Downloads all authorized fan decks and certain system files, and creates a backup file on your computer. The backup file could then be restored to a computer that does not have on-line access.

Restore file cache

Restores fan decks and certain system files from a backup file.

Help

Open the help document.

Register product

Open the registration page where product registration occurs.

Check for updates

Check for available software updates.

About CAPSURE Sync

Display the version of the software application installed.

Exit

Close the application. Note: The application runs in the background by default whenever you start your computer. If you quit the application, you will have to restart the computer or restart the application to use it. Plugging in the CAPSURE instrument will not restart the application; you will need to start it as described at the beginning of this document.